



# M5600/U5600 Installation Manual

## Wireless Pressure Transducers



### your distributor

AMSYS GmbH & Co.KG

An der Fahrt 4, 55124 Mainz, Germany


Tel. +49 (0) 6131 469 875 0

info@amsys.de | www.amsys.de





# M5600/U5600 INSTALLATION MANUAL

Wireless Pressure Transducers

## 5600 Standard Transducer Matrix



Application and Installation

<b>Wireless Application</b>		 <b>Precautions</b>
		<p>Before installation, please verify that the product matches its intended use, especially the pressure fitting, pressure range,</p> <hr/> <p>Sensitive diaphragm inside. Do not stick anything into the pressure port.</p> 
Smart phones version	<p><b>App:</b></p> <p style="padding-left: 20px;">&gt; TE sensor Tag.apk</p> <p><b>Receiver Operating System:</b></p> <p style="padding-left: 20px;">&gt; Andriod 4.3 or IOS 7 above</p> <p><b>*DETAIL REFER TO 'Wireless development kits'</b></p>	
Windows version	<p><b>Hardware &amp; System:</b></p> <p style="padding-left: 20px;">&gt; PC with USB serial port support</p> <p style="padding-left: 20px;">&gt; Dongle: BT900-US</p> <p style="padding-left: 20px;">&gt; Operation System: Windows XP, Windows 7 or above</p> <p><b>*DETAIL REFER TO 'Wireless development kits'</b></p>	
<b>Battery Installation</b>	<b>Installation</b>	<b>Uninstallation</b>
		<p>&gt; OPEN THE BATTERY DOOR</p> <p>&gt; PRESS BATTERY EDGE TO POP IT</p> 

NOTES:



1. DON'T INSTALL BATTERY WHEN NOT IN OPERATION.
2. TORQUE DEPENDS ON DIFFERENT PARAMETERS SUCH AS SEALING MATERIAL, MATING MATERIAL, THREAD LUBRICATION AND PRESSURE LEVEL. TFFT MEANS TURNS FROM FINGER TIGHT.
3. THE "PORT TYPE" MAY NOT BE ALL APPLICABLE TO CUSTOMER SPECIALS. BE CAUTIOUS ON THE DIFFERENCES ESPECIALLY
4. BATTERY: SONY CR2050W OR CR2032W
5. FOR MORE PRODUCT INFORMATION, PLEASE REFER TO OUR WEBSITE: [WWW.TE.COM](http://WWW.TE.COM)

## M5600/U5600 INSTALLATION MANUAL

Wireless Pressure Transducers



### your distributor

AMSYS GmbH & Co.KG

An der Fahrt 4, 55124 Mainz, Germany

Tel. +49 (0) 6131 469 875 0

info@amsys.de | www.amsys.de

### NORTH AMERICA

Measurement Specialties, Inc.,  
a TE Connectivity company  
45738 Northport Loop West  
Fremont, CA 94538  
Tel: +1 800 767 1888  
Fax: +1 510 498 1578  
[customercare.frm@te.com](mailto:customercare.frm@te.com)

### EUROPE

MEAS France SAS,  
a TE Connectivity company  
4 Rue Gaye Marie  
31027 Toulouse, France  
Tel: +33 (5) 822 822 00  
Fax: +33 (5) 820 821 51  
[customercare.flse@te.com](mailto:customercare.flse@te.com)

### ASIA

Measurement Specialties (China) Ltd.,  
a TE Connectivity company  
No. 26 Langshan Road  
Shenzhen High-Tech Park (North) Nanshan District,  
Shenzhen, 518057  
China  
Tel: +86 755 3330 5088  
Fax: +86 755 3330 5099  
[customercare.shzn@te.com](mailto:customercare.shzn@te.com)

### [te.com/sensorsolutions](http://te.com/sensorsolutions)

Android is a trademark of Google Inc.

Google Play is a trademark of Google Inc.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Microsoft, Encarta, MSN, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Android and Windows are trademarks of their respective owners.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by TE Connectivity is under license. Other trademarks and trade names are those of their respective owners.

Measurement Specialties Inc., a TE Connectivity company.

Measurement Specialties (MEAS), American Sensor Technologies (AST), TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.

M/U5600 IS, Rev A  
Doc No. MSI07559